

## Top (-T) Assembly Instructions



1. Position the base units in the approximate position for the top.



2. You mount the top to the base units by screwing directly up through the wooden mounting strips from below.



3. Lower the top onto the base units. Position the base unit(s) where you like.



4. Using four 1 1/4" course thread wood screws, attach the base unit to the top by screwing up through the mounting strip into the top. Be careful not to countersink the screws too far.